

First Workshop ARENHA project: "Introduction to novel technologies related to ammonia-based energy storage"

Development of solid state ammonia absorption and storage

Anastasiia Karabanova Contact: anaka@dtu.dk

This project has received funding from the European Union's Horizon 2020 research and innovation programme under grant agreement No 862482



The present publication reflects only the author's views. The Commission is not responsible for any use that may be made of the information contained therein.







- I. Why's?
- 2. Applications
- 3. How does it work?
- 4. Materials
- 5. Modelling of storage tank
- 6. Model validation





Solid metal salts can form stable metal ammines (SrCl₂, MgCl₂, CaCl₂, etc.)

- Partial pressure of ammonia at RT is low (2 mbar 0.7 bar vs. 16 25 bar for liquid storage)
 - Solves safety issues for mobile applications
 - Enables low pressure ammonia synthesis
- Volumetric hydrogen density is high



Volumetric hydrogen capacity by 8 hydrogen storage methods

First ARENHA Workshop, ENGIE Lab CRIGEN (April 7th, 2022) (Reproduction without prior permission of ARENHA is prohibited).

Klerke et al., 2008

07/04/2022 Page 3



 \geq



2. Solid state ammonia absorption and storage: Applications

- Ammonia for hydrogen storage and transportation -ARENHA
- Ammonia for deNO_x of diesel engines exhausts -AMMINEX
- Ammonia absorber for low pressure ammonia synthesis -AREHNA



 $DeNO_x$ vessel from AMMINEX. Capacity 3 kg_{NH3}





(Reproduction without prior permission of ARENHA is prohibited).

4. Solid state ammonia absorption and storage: Materials



areNH₃a

4. Solid state ammonia absorption and storage: Materials





areNH₃a

First ARENHA Workshop, ENGIE Lab CRIGEN (April 7th, 2022) (Reproduction without prior permission of ARENHA is prohibited).



Goal: to develop an accurate numerical model of solid state ammonia storage tank

 $Sr(NH_3)_1Cl_2 + 7NH_3 \leftrightarrow Sr(NH_3)_8Cl_2 + Q$



First ARENHA Workshop, ENGIE Lab CRIGEN (April 7th, 2022) (Reproduction without prior permission of ARENHA is prohibited).

Soprani, 2016





Model: 3D, time-dependent

Software: COMSOL Multiphysics

Physics:

- I. Mass transfer \rightarrow pressure **p** and velocity **u**
- 2. Reaction kinetics \rightarrow reaction advancement *x*
- 3. Heat transfer \rightarrow temperature *T*

Domains:

- I. Honeycomb disc
- 2. Reactive bed (porous medium = salt + gas)
- 3. Gaseous ammonia





Physics:

- I. Mass transfer \rightarrow pressure **p** and velocity **u**
- 2. Reaction kinetics \rightarrow reaction advancement x
- 3. Heat transfer \rightarrow temperature T

Required parameters:

- I. Honeycomb disc: ρ_{hd} , $C_{p_{hd}}$, k_{hd}
- 2. Reactive bed: ρ_{eff} , $C_{p_{eff}}$, k_{eff} , ε , κ
- 3. Gaseous ammonia: ρ_{NH_3} , $C_{p_{NH_2}}$, k_{NH_3} , μ





First ARENHA Workshop, ENGIE Lab CRIGEN (April 7th, 2022) (Reproduction without prior permission of ARENHA is prohibited).





2. Reaction kinetics

$$\frac{dx}{dt} = k_0 e^{-\frac{E_a}{RT}} f(x)h(P)$$
$$x = \frac{SrCl_{2reacted}}{SrCl_{2total}}$$

Kinetic tetrad
$$T \rightarrow \begin{bmatrix} k_0 & \text{-pre-exponential factor} \\ E_a & \text{-activation energy} \\ x \rightarrow f(x) & \text{-reaction model function} \\ p \rightarrow h(p) & \text{-pressure impact function} \end{bmatrix}$$

First ARENHA Workshop, ENGIE Lab CRIGEN (April 7th, 2022) (Reproduction without prior permission of ARENHA is prohibited).



I. Y.Yuan et al., "Investigation of equilibrium and dynamic performance of SrCl2-expanded graphite composite in chemisorption refrigeration system," Appl.Therm. Eng., vol. 147, no. January 2018, pp. 52–60, 2019.

m_{sorbent} = 210 g

2. Huang et al., Modeling of gas-solid chemisorption in chemical heat pumps," Sep. Purif. Technol., vol. 34, no. 1–3, pp. 191–200, 2004.

 $m_{sorbent} = 2100 g$





Barometric Sievert's type apparatus



$$\Delta p \to x$$



First ARENHA Workshop, ENGIE Lab CRIGEN (April 7th, 2022) (Reproduction without prior permission of ARENHA is prohibited).



DTU

5. Solid state ammonia storage tank: Modelling

Reaction kinetics : Absorption

Mass - 71 mg

 $Sr(NH_3)_1Cl_2 + 7NH_3 \leftrightarrow Sr(NH_3)_8Cl_2 + Q$





5. Solid state ammonia storage tank: Modelling

Reaction kinetics : Desorption



 $Sr(NH_3)_8Cl_2 + Q \leftrightarrow Sr(NH_3)_1Cl_2 + 7NH_3$



First ARENHA Workshop, ENGIE Lab CRIGEN (April 7th, 2022) (Reproduction without prior permission of ARENHA is prohibited).





Model: 3D, time-dependent

Software: COMSOL Multiphysics

Physics:

- I. Mass transfer \rightarrow pressure **p** and velocity **u**
- 2. Reaction kinetics \rightarrow reaction advancement *x*
- 3. Heat transfer \rightarrow temperature *T*

Domains:

- I. Honeycomb disc
- 2. Reactive bed (porous medium = salt + gas)
- 3. Gaseous ammonia



Modelled distribution of reaction advancement during desorption





First ARENHA Workshop, ENGIE Lab CRIGEN (April 7th, 2022) (Reproduction without prior permission of ARENHA is prohibited).

Karabanova et al., 2021



We need: validated numerical model.

Validation methods:

- I. Comparison to a reference solution
- 2. Experimental data:

Combination \checkmark Local (thermocouple) \rightarrow T at specific points \checkmark Global (flowmeter) \rightarrow global reaction advancement x

Our solution: Neutron Radiography

We can follow the state of the sorbent at **each point** of the storage tank





What is Neutron Radiography?

Similar to X-ray radiography

But X-rays ≠ Neutrons!

Neutrons can "see" hydrogen and hence ammonia













Karabanova et al., 2021





The Beer-Lambert's law

$$I = I_0 \cdot e^{-d \cdot \mu}$$

DTU

First ARENHA Workshop, ENGIE Lab CRIGEN (April 7th, 2022) (Reproduction without prior permission of ARENHA is prohibited).



$$Sr(NH_3)_8Cl_2 + Q \leftrightarrow Sr(NH_3)_1Cl_2 + 7NH_3$$

 $P \approx 1 \text{ bar}$





First ARENHA Workshop, ENGIE Lab CRIGEN (April 7th, 2022) (Reproduction without prior permission of ARENHA is prohibited).

Karabanova et al., 2021 07/04/2022 Page 22







areNH₃a

DTU





Karabanova et al., 2021 07/04/2022 Page 23



DTU



I. Solid metal salts can form stable metal ammines (SrCl₂, MgCl₂, CaCl₂, etc.).

- Systems with metal ammines can be used as solid state ammonia storage tank, deNO_x vessels, as well as absorber for low pressure Haber Bosch process.
- 3. Knowledge model of storage tank shown in this presentation can be used for any geometries, materials, and applications.

 \checkmark

Neutron radiography is a powerful tool to validate numerical models of ammonia-based systems.



Development of solid state ammonia absorption and storage

First Workshop ARENHA project, ENGIE Lab CRIGEN, 07-04-2022

Thank you for your attention

Website project: https://arenha.eu/

Contact: anaka@dtu.dk



First ARENHA Workshop, ENGIE Lab CRIGEN (April 7th, 2022) (Reproduction without prior permission of ARENHA is prohibited).